



HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה


נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.


יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.


על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:




מקמו את הפריטים הכבדים ביותר במגירה התחתונה. הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.




אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.













1




10050769

2x




10050771

2x



151706
151708

6x




151705
151707

6x



101345

5x




105811

2x




146114
1004962

18x




10051650
10051660

8x




10003780

1x



153548
158568

2x



10040039
10051022

2x




10

A



118331

12x




119976

6x



146114

18x



159553


145718

12x



101345


10x



119030


118224

24x



10052019

6x




10040242

3x



24





10043622







10050475

3x


1




2




3




4




5




6




7




8





9




10




11




12




13







15



16





17


English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


עברית


הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm (5/16") 


1 


2  70 mm (2 3/4")


3 


B




Ø 8 mm (5/16") 


1 


2  ≈ 30 mm (≈ 1 1/4")


3 


C





Ø 3 mm (1/8") 






1 

2  ≈ 30 mm (≈ 1 1/4")



3 

18







20




21







22




23




24




25




26




27




28



29



30



English**Care and cleaning**

Wipe clean with a cloth damped in a mild cleaner.

Wipe dry with a clean cloth.

עברית**Care and cleaning**

נקו בעזרת מטלית וחומר ניקוי נוזלי.

נגבו לייבוש בעזרת מטלית רכה.

